







Ceramic Tile Underlay

Ideal ceramic tiles laying substrate Ceramic Tile Underlay

PRÎMA*CTU* is a premium quality autoclaved cellulose fibre reinforced cement board manufactured from Portland cement, top grade quality pulp from New Zealand, finely ground sand and water. Saint-Gobain Prima Sdn Bhd, a manufacturing plant that is accredited by MS ISO 9001:2000.

PRÎMACTU has superior fire performance and dimensional stability, which makes it an ideal substrate for ceramic tiles in wet and dry areas.

Manufactured with a pre-marked nailing pattern, sheets can be easily laid on existing timber flooring with minimal surface preparation.

Product Features & Benefits

- Water Resistant
- Termite Resistant
- Fire Resistant
- Fungus Resistant
- Impact Resistant
- Good Workability
- Structurally Strong
- Reduces tile movements.
- Flat surface for smooth ceramic tile finishing.
- \bullet Pre-printed fastener points for ease of installation.
- Square cut edges for neat sheet jointing.
- Fibre cement superiority with lasting durability.
- Simple and easy installation.
- No stripping of old floor boards.
- Applicable in wet and dry areas.
- Less cutting and joining for large/wider areas.

Standard Sizes

PRÎMA <i>CTU</i> ™ standard thickness is 6.0mm. Its mass at EMC is approximately 8.8kg/m²			
Thickness (mm)	Width (mm)	Length (mm)	
6.0	900	1800	
	1200	1800	

Note: Other sizes are available on special order and may be subject to special conditions.



Handling & Finishing

PRÎMA*CTU*[™] should be overlaid with ceramic, mosaic or marble tiles. Use a compatible flexible tile adhesive. Ensure the sheet surface is free from dust or other contaminants prior to tiling. Refer to your tile adhesive manufacturer for more details.

Underfloor Preparation Ventilation

Existing Floorboards

Ensure that the underside of the existing floor is adequately ventilated and free from dampness.

Check and replace any damaged floorboards and firmly renail any loose boards. The surface must be reasonably flat. Rough-sand any undulation prior to fixing the ceramic tile underlay

Installation Steps

Handling & Finishing

Step 1



Cut the **PRÎMA** CTU" using a "score and snap" knife. Use a straight edge as a guide while scoring a minimum of 1/3 of sheet thickness.

Step 2




Hold the sheet firmly near the cut, while snapping the off-cut upward to break.

Step 3



Lay **PRÎMA**CTU^{**} across the floorboard direction in a staggered (brick) pattern. Sheet joints must not coincide with floorboard joints (provide a minimum of 100mm offset). Allow a minimum of 3mm gap between sheet edges and walls.

Step 4



Fasten **PRÎMA**CTU™ from centre and working outwards using the pre-printed nailing pattern. Use 25mm x 2.5mm0 underlay nails. Drive nails flush with sheet surface.

Step 5



Apply tile adhesive onto **PRÎMA**CTU™ using a notched trowel. Refer to adhesive manufacturer's instructions.

Step 6



Lay ceramic tiles in accordance with tile manufacturer's recommendations.


Sheet Fixing Illustrations

Sheet Layout



PRÎMA CTU™ can be fixed directly to existing timber, particleboard or plywood floor. Ensure that the existing floorboard is flat and in good condition prior to fixing the underlay sheets at the pre-marked fixing positions. Underlay sheets should be laid in staggered or brick pattern.

PRÎMA $CTU^{\circ\circ}$ sheets should be laid in a staggered or brick pattern, across the direction of floorboards. Sheet joints must not coincide with floorboard joints as shown in Figure 1.



Perimeter Expansion Gap

Leave a 3mm gap between sheet edges and wall at the wall-to-floor junction as shown in Figure 2.




Figure 2: Perimeter Expansion Gap

Fastener Specification

Use 25mm x 2.5mm0 annular threaded underlay nails. Nail fixing locations must be as the following:

- 12mm minimum from sheet edge
- · 50mm minimum from corner
- 75mm maximum centres at perimeter
- · 150mm maximum centres elsewhere

Drive nail heads flush with the underlay sheet surface. Commence nalling from the sheet centre and work outwards towards the sides and ends of sheet. Refer to Figure 3.

Note: For fixing to particleboard or plywood floor, apply wallboard adhesive to the rear of sheet with a 3mm notched trowel in addition to nail fixing as specified above.




Figure 3: Fixing Locations

Expansion Joints

Expansion joints must be provided at 5.0m maximum centres and must always coincide with the structural break joints of the existing floor structure. Refer to Figure 4.




Figure 4: Detail at Expansion Joint

Tile Adhesive & Grout

Use only flexible tile adhesive which comply to AS 2358 - Adhesive for fixing ceramic tiles. Refer to tile adhesive manufacturer for recommendations. Grouting material must be fully compressible.

Tiling

Tiles should be laid in accordance with acceptable tile laying practice. Provide a minimum of 2mm to 3mm gap between each tile.

AS/NZS 2908.2 ASTM C1186 Fire Resistance AS 1530.3

Termite Resistance - tested by CSIRO































For more information, please contact us at:



SAINT-GOBAIN PRIMA SDN BHD (579898-W)

Level 19, Tower 5, Avenue 7 The Horizon, Bangsar South City, No. 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia

General Line 1: +603 7781 1977 | General Line 2: +6012 781 1797

🕥 www.primafibrecement.com | www.saint-gobain.my

